


Grundfos Redi-Flo4™ Parts Numbers

Position Number	Part Numbers	Description
1	085052	Upper Chamber
1b	055006 085022 085047	Discharge 1½" NPT Discharge 1" NPT Discharge 1¼" NPT
3a	080041	Valve Seat Support
7	91121961 91121960	Seal Ring (old p/n # 050005) Bearing (old p/n # 050004)
9	055017 095065	Int. Chamber 25E Int. Chamber 5E, 10E, 16E
10	085030	Lower Chamber with Screen
12	ID7253	Lock Nut for Shaft
13	055001 085023 085048 085050	Impeller 25E Impeller 5E Impeller 10E Impeller 16E
14	085020	Inlet
16	086203 086204 086205 086206 086207 086208 086209 086211 086212 086213 086214 086219 086221 086225 086217	Shaft 5E3 Shaft 16E4 & 25E4 Shaft 5E5, 10E5 Shaft 25E6 Shaft 16E7 Shaft 5E8, 10E8 & 25E8 Shaft 16E9 Shaft 10E11 Shaft 5E12 Shaft 16E13 Shaft 10E14 Shaft 10E19 Shaft 5E21 Shaft 5E25 Shaft 5E17
17	089203 089204 089205 089206 089207 089208 089209 089211 089212 089213 089214 089217 089219 089221 089225	Strap 5E3 Strap 16E4 & 25E4 Strap 5E5, 10E5 Strap 25E6 Strap 16E7 Strap 5E8, 10E8 & 25E8 Strap 16E9 Strap 10E11 Strap 5E12 Strap 16E13 Strap 10E14 Strap 5E17 Strap 10E19 Strap 5E21 Strap 5E25
18	084603 084604 084605 084606 084607 084608 084609 084611 084612 084613 084614 084617 084619 084621 084625	Cable Guard 5E3 Cable Guard 16E4 & 25E4 Cable Guard 5E5, 10E5 Cable Guard 25E6 Cable Guard 16E7 Cable Guard 5E, 10 & 25E8 Cable Guard 16E9 Cable Guard 10E11 Cable Guard 5E12 Cable Guard 16E13 Cable Guard 10E14 Cable Guard 5E17 Cable Guard 10E19 Cable Guard 5E21 Cable Guard 5E25
19	ID3943	Bolt for Straps
64	080051	Priming Inducer
71	410026	Washer
84	100081	Cover Plate
NS	090032	Washer
NS	100081	Cover Plate



REFERENCE PAGES